


FFAG Optics and Design


J. Scott Berg
Brookhaven National Laboratory
FFAG17 School
September 7, 2017

- Superperiods
- Energy-dependent periodic orbits


- FFAGs generally consist entirely of a single simple, identical cells, repeated around the ring
 - The cell generally only has two magnets, though occasionally more
- This means we can focus only on the superperiod: a single cell
 - We only need worry about the linear resonances of the single cell
 - This is what allows a wide range of energy stability



- Ignore RF, energy doesn't change
- For some range of energies, you can find an orbit whose phase space coordinates at the beginning of the cell are identical to its phase space coordinates at the end of a cell: periodic orbit



- Phase space coordinates are relative to a local coordinate system
 - A cell has a design bend; the coordinate system rotates by this amount as well
 - The periodic orbit bends by the design angle in floor coordinates
 - That angle is the same for every energy
- Each orbit has a tune; this tune is for the single cell
- The tune depends on energy
- For a linear FFAG, this tune variation bounds the energy range
 - Half integer at low energy, zero tune at high energy



- Construct a single cell
- Compute periodic orbits
 - `parameter [geometry]=closed`
- Use multiple universes for different energies
 - `n_universes` in `&tao_design_lattice`
 - change `n@beam_start pz @(dp_on_p)` to set energy for universe `n`
- Can plot versus energy
 - `curve(n)%data_type_x='beam_start [pz]'`

- Execute tao on the example given
- Identify the horizontally focusing and defocusing magnets
- Where longitudinally is the beta function the lowest?
- The orbits are evenly spaced in energy; are their horizontal positions evenly spaced?
- Have Bmad display the tune at the lowest energy
- Create a plot with horizontal beta functions or dispersions vs. position for different energies
- Plot the beta function vs. energy at the defocusing quad center

- Want to keep apertures reasonably small
- Reduce variation of periodic orbit position with energy
- This is related to dispersion (which is the local derivative of orbit position with respect to energy)

- For coordinates x and momenta p_x , we can write

$$x = \sqrt{\beta} w_1 \quad p_x = -(\alpha w_1 + w_2) / \sqrt{\beta}$$

- $w_1^2 + w_2^2$ is invariant for a linear lattice
- Consider similar quantities for dispersion


$$D_x = \sqrt{\beta_x} \xi_1 \quad D_p = -(\alpha_x \xi_1 + \xi_2) / \sqrt{\beta_x}$$

- $\xi_1^2 + \xi_2^2$ is *not* invariant; but it only changes in magnetic fields

$$\frac{d(\xi_1^2 + \xi_2^2)}{ds} = 2\sqrt{\beta_x} \frac{qB_y}{p} \cos \phi_\xi$$

- Generally, horizontal beta functions are smallest at a defocusing quadrupole
- Thus, want to bend near the defocusing quadrupole
- Thus, at least in non-scaling FFAGs, we used combined-function defocusing quadrupoles
 - On average, more bend happens in the defocusing quadrupole
 - But that's not true for every orbit

- Generally dispersion is proportional to $L\theta$: the cell length times the bending angle
- Generally try to make the cell length as short as possible
- Hardware will limit your cell length
- Generally have at least one “long drift”; needed for RF, injection/extraction, diagnostics, etc.
 - Even if you don’t need these things in every cell, every cell must have the long drift
- Often make other drifts “short” to reduce cell length
 - Still have some realistic lower limits




- Consider magnet strengths
 - Shorter magnets require higher fields: inversely with magnet length
 - Shortening drifts increase magnetic fields also, roughly inversely with cell length
- Ratio of magnet aperture to magnet length should not be too large

- Magnets will still generally be short
 - Magnets don't simply have “body fields”
 - Maxwell's equations force certain additional field patterns on the ends
 - Fields are not localized within the magnet “body”; length scale proportional to aperture
 - The relative effect of these is larger with shorter magnets
- Magnet “end fields” can be modelled in Bmad
 - `fringe_type`
 - Soft-edge parameter `fq1` and `fq2`

- Higher horizontal tunes will reduce dispersion
- Tunes rise very rapidly as approach the half-integer per cell
- Best use of magnets is generally to have low vertical tunes (which have little impact on orbits), high horizontal tunes
- Linear magnets: tunes naturally reduce at higher energy
 - Roughly as $1/p$ for very high energies
 - Dispersion rises, orbits spread out
 - This gives a practical limitation on energy range
- Beware of vertical instability at high energies


- Magnet layout is generally described with some coordinate system
 - Representation in design code is not always straightforward
- There is no “reference orbit” that follows the coordinate system
 - There can be, but this is generally not the best representation
- There are many ways to do this
- The coordinate system should be related to your hardware
 - How your beam pipe is laid out
 - What your magnets look like
 - Field representation should correspond to the actual magnet

Traditional MAD-like geometry




- Combined-function defocusing quadrupole
- All coordinate bending in that magnet
- Lines of constant field are arcs
 - Your magnet probably doesn't do this
- No coordinate patches
- There can be an orbit that follows the geometry

True rectangular combined-function magnet




- Lines of constant field are straight lines
 - sbend, b_field=0, b_field_err=...
- Patches at magnet ends to rotate coordinate system
 - patch, x_pitch=...

Shifted quadrupoles




- Use shifted quadrupole instead of combined-function magnet
 - quadrupole, `x_offset=...`

Layout on a circle




- Segments are chords of a circle of a given radius
- Coordinate patches between segments

Curved drift



- As before, now drifts are in a curved coordinate system
 - sbend, $g=g_0$, $g_err=-g_0$
- Still have coordinate patches

Curved drift, no patches



- All bending in drifts
- No more patches

- There are 6 lattices matching the above geometries
- Copy the tao files into two directories (for comparison)
- Renaming the desired example to `cell.bmad`
- Which examples should be the same? Are they?
Check tunes, orbits.
- Set `fringe_type` to `full`; what changes?
- Change a dipole field and describe the effects
- Change the quadrupole strengths and describe the effects

- The cell has four parameters: two dipole fields, two quadrupole fields
- There are three “obvious” criteria
 - Centering the beam in the pipe
 - Low energy horizontal tune high, but not too high
 - High energy vertical tune low, but not too low
- Tune choices are affected by other criteria at times (resonances, magnet fields, etc.)
- The remaining free variable can optimize various things
 - Aperture
 - Magnet design parameters
 - “Cost”

- Optimization criteria have been set up; what do they do?
- I modified one of my lattices from the previous exercises; why?
- How would the variables be modified if you were using shifted quadrupoles?
- Run the optimization; describe the results.
- Change the target tunes, one at a time; what happens to the orbits?
- Optimize fitting only the tunes and center the orbits. One variable should not be varied (which?). Examine results as you change that variable.

- Criteria
 - 5 m radius of curvature
 - Minimum drifts: 11 cm long, 6 cm short
 - Energy range: 42 MeV to 150 MeV
- Use one of the existing examples as a starting point
- Make plots showing four energies: 42, 78, 114, 150 MeV